

Scooter Accessories

Accessories



Seat Suspension

Easily installs into the scooter seat post to provide a softer ride.

Leo Model nos. 1541628 (L) / 1541629 (M)

Colibri Model nos. 1577212 (L) / 1577213 (M) / 1577214 (T)

Pegasus Model nos. 1522456 (L) / 1522457 (M) / 1522458 (T)



Walker Holder

Keeps a walker secure during travel.

Model no. ACC210

Comet HD scooter requires 1541502, Scooter Accessory Tube (shown). Colibri scooters require 1148158, Scooter Accessory Bracket



Cane and Forearm Crutch Holder

Keeps a cane or forearm crutches stable and within reach during transit.

Model no. ACC200

Comet HD scooter requires 1541502, Scooter Accessory Tube. Colibri scooters require 1148158, Scooter Accessory Bracket



Scooter Cover

Heavy duty black nylon cover protects the scooter from the elements.

Model no. PRC571840

For Colibri™ and Leo scooters only

Model no. 1518240

For Pegasus, Comet and Comet HD scooters only



Phone/Wallet/Comet HD Pneumatic Bulb Arm Pocket

Attaches to the scooter armrest.

Model no. 12511



Accessory Bracket

Attaches securely to the seat frame of the Colibri scooter to accommodate the use of one rear accessory.

Model no. 1148158

For Colibri™ scooters only